

PACKAPOST™

Before setting up the Rugby Posts these instructions **MUST** be fully read and understood. Failure to do so may result in damage and/or injury and void your equipment warranty.

SET UP

1



Step 1: Find a level surface and remove rugby uprights (x2) and crossbar pieces (x3) from bags.

2



Step 2: Layout uprights as shown ensuring hose is not twisted.

3



Step 3: Remove the dust cap and turn valve fully anti-clockwise (i.e. toward inflate mark) which closes the valve and retains the air in the hose after inflation.

4



Step 4: Connect the hose of the air pump (to the bottom connector) and pump to **FULLY INFLATE** uprights. Replace dust caps to valves.

5



Step 5: Slot together crossbar pieces. **IMPORTANT – FULLY ENGAGE PUSH BUTTON** spring clips into each of the holes in the crossbar end sections.

6



Step 6: Connect crossbar to upright. **IMPORTANT – FULLY ENGAGE PUSH BUTTON** spring clips into each of the holes in the upright connectors.

7



Step 7: Attach guy ropes to uprights (as shown). At this point you can also screw in flag holders into the top of the uprights (flags NOT INCLUDED).

8



Step 8: Raise rugby post to upright position and secure the feet and back stanchion of the upright using ground anchors supplied.

9



Step 9: Use 3 x ground anchors per upright - two on inflatable feet and one at rear of back stanchion (more can be used if required). Sand/water bags should be used on astro turf.

It is recommended that guy ropes are always used to provide additional stability - to avoid accidents care **MUST** be taken to ensure guy rope supports & pegs are labelled (e.g. with high vis. cones or training discs).

10



Step 10: Extend connected guy ropes and secure to the side and behind - for guidance this is approx. 3 feet (1m) to the side and 6 feet (2m) behind.

11



Step 11: To avoid accidents, care **MUST** be taken to ensure guy rope supports are labelled (e.g. with high visibility cones or discs – not always supplied as standard).

12



Step 12: Now you are ready to train and play.

PACKAWORLD
BRING THE GAME

PACKAWAY




Step 1: Remove ALL ground anchors and guy ropes.




Step 2: Carefully lay post to the ground. **IMPORTANT** ensure posts do not fall as this will damage posts. At this point you can remove flag holders & flags (if fitted).



Step 3: Remove dust cap and turn the valve insert, of each upright, fully clockwise to release air. This may require a little push and wiggle to the valve insert.



Step 4: Remove the crossbar from uprights by depressing buttons. Continue to remove other sections of crossbar to dismantle. Pack away in the bag provided.



Step 5: Remove ALL residual air from the uprights. To do this move pump hose to top connector and connect other end of pump hose to valve on upright. Air extraction will begin when pumped.



Step 6: Once ALL air extracted from uprights, return all valves to closed position, replace dust caps and fold away uprights and crossbar into bags.



IMPORTANT INFORMATION – PLEASE READ BEFORE USING EQUIPMENT



PACKAWORLD DOES NOT WARRANT THE USE OF FULL-SIZE RUGBY PACKAPOSTS UNDER OR FOR COMPETITIVE GAME CONDITIONS. PACKAWORLD DOES NOT ACCEPT ANY LIABILITY WHATSOEVER FOR ANY LOSSES OR DAMAGE THAT RESULT DIRECTLY OR INDIRECTLY FROM THE USE OF PACKAPOSTS IN COMPETITIVE RUGBY GAMES. FOR FURTHER INFORMATION ON WARRANTY GO TO <https://www.packaworld.com/warranty--returns.html>.

1. Do not use Packaposts in winds greater than 17 mph / 15 knots (Moderate Winds). Higher wind conditions will compromise the stability of the Packaposts and may cause damage and/or injury and void equipment warranty.
2. Never drag the inflated Packapost on hard ground as **IT WILL** damage the hoses that make up the posts.
3. **ONLY** use the hand pump provided to inflate uprights as high pressure mechanical appliances can damage hoses and/or valves and cause injury.
4. For ease of packing, make sure you extract the residual air with hand pump before rolling Packapost uprights back into the bag.
5. For ease of assembly and disassembly it is important to keep crossbar section inserts lubricated with petroleum jelly (Vaseline) or silicone spray.
6. Do not use Packapost for other than temporary purposes nor leave exposed outside for prolonged periods of time. Exposure to adverse weather conditions and the sun's ultraviolet rays can damage the Packapost and/or cause them to discolour.

Failure to completely follow these guidelines could damage your Packapost, cause personal injury and void your Warranty. For further Care & Maintenance information go to <https://www.packaworld.com/packapost-instructions.html>

PLEASE NOTE THAT PACKAWORLD PRODUCTS ARE TEMPORARY STRUCTURES AND ARE NOT SUITABLE FOR LONG TERM EXPOSURE OUTDOORS. OVER A PERIOD OF TIME THE INFLATABLE UPRIGHTS WILL LOSE AIR AND AS SUCH WILL REQUIRE TOPPING UP WITH THE AIR PUMP SUPPLIED.